

Security Solutions

The Advantage Scientific 6-tumbler dead bolt locking system provides added security and maximum flexibility. Keying is available in key-a-like, key-different and masterkeyed, with 250 in-stock key changes.



Core removal feature allows flexible re-keying by use of the core key. Locks may be easily re-cored with different key combinations without complete lock replacement.



Trim bezel and two keys are included. Keys are double-bit, allowing insertion up or down. Lock face and keys have key number stamp.



Diecast lock body houses lock core mechanism and positive dead bolt sliding tang.



Dead bolt tangs securely engage into grooves or stop tabs.

ANSI/BHMA A-156.11-2010 Grade 1/BIFMA certified.

6-tumbler system provides greater security and larger number of key changes.

Red core key allows in-field re-keying without major refurbish and time expense.

Blue master key provides supervisory access.

Double-bit grind keys ensure easy use and insertion.

Key-out feature in both locked and unlocked positions.

Key-a-like and key-different applications.

Locks are masterkeyed for supervision oversight and access.

NO MORE barrel style locks requiring stamped washer and jamb nut.

NO MORE rotating cam stops and fixing screw to loosen.

NO MORE rotating tangs easily bent, loosened or vandalized.



KEYED ALIKE
SA402CA

KEYED DIFFERENT
SA402CD